


61.149.221.157 PD36R ACE说明书
105G铜板纸/单黑双面印刷/225*490mm/风琴折后56*98mm/A0

FENIX LIGHTING FOR EXTREMES
PD36R ACE
MULTI-MODE TACTICAL FLASHLIGHT
3000 LUMENS MAX OUTPUT
415 METERS MAX BEAM DISTANCE



TECHNICAL PARAMETERS table with columns: ANSIPLATO FL1, TURBO, HIGH, MED, LOW, ECO, STROBE, SOS. Rows include Output, Runtime, Distance, Intensity, Impact Resistance, and Submersible status.

1(f) (output)→Option 2(f) (outputs)→Option 3(f) (outputs). When users turn on the flashlight for the first time, Option 3 will be selected by default.
Note: 1. Users can turn the Strobe mode on or off separately. It is turned on in all options by default.

Table with 10 columns: Mode, Eco, Low, Med, High, Turbo, Strobe, SOS, SOS, SOS. Rows show different lighting modes and their corresponding settings.

警告
请勿将本灯放置在儿童接触得到的地方，避免儿童使用！
请勿将本灯直接照射眼睛，以免为眼睛造成伤害！

技术参数 table with columns: ANSIPLATO FL1, 亮度, 续航时间, 射程, 光强, 防跌落高度, 防护等级. Rows provide technical specifications for the flashlight.

1. 开关状态下，长按顶部功能开关0.5秒以上进入爆闪模式，再次单击顶部功能开关，切换到SOS模式，再次长按0.55返回之前照明方案档位。
2. 开关状态下，长按SET按钮1.25可关闭/打开所有方案下的爆闪模式，而头灯模式则不受影响。

Table with 2 columns: 亮度, 续航时间. Rows show different lighting modes and their corresponding runtime.

警告
1. 请勿将本灯放置在儿童接触得到的地方，避免儿童使用！
2. 请勿将本灯直接照射眼睛，以免为眼睛造成伤害！

TECHNISCHE DATEN table with columns: ANSIPLATO FL1, TURBO, HELL, MITTEL, DUNKEL, ECO, STROBE, SOS. Rows include Leistungsstufe, Reichweite, Leuchtkraft, and other technical data.


Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.



TECHNICAL PARAMETERS table with columns: ANSIPLATO FL1, TURBO, HIGH, MED, LOW, ECO, STROBE, SOS. Rows include Output, Runtime, Distance, Intensity, Impact Resistance, and Submersible status.

1(f) (output)→Option 2(f) (outputs)→Option 3(f) (outputs). When users turn on the flashlight for the first time, Option 3 will be selected by default.
Note: 1. Users can turn the Strobe mode on or off separately. It is turned on in all options by default.

Table with 10 columns: Mode, Eco, Low, Med, High, Turbo, Strobe, SOS, SOS, SOS. Rows show different lighting modes and their corresponding settings.

警告
1. 请勿将本灯放置在儿童接触得到的地方，避免儿童使用！
2. 请勿将本灯直接照射眼睛，以免为眼睛造成伤害！

技术参数 table with columns: ANSIPLATO FL1, 亮度, 续航时间, 射程, 光强, 防跌落高度, 防护等级. Rows provide technical specifications for the flashlight.

1. 开关状态下，长按顶部功能开关0.5秒以上进入爆闪模式，再次单击顶部功能开关，切换到SOS模式，再次长按0.55返回之前照明方案档位。
2. 开关状态下，长按SET按钮1.25可关闭/打开所有方案下的爆闪模式，而头灯模式则不受影响。

Table with 2 columns: 亮度, 续航时间. Rows show different lighting modes and their corresponding runtime.

警告
1. 请勿将本灯放置在儿童接触得到的地方，避免儿童使用！
2. 请勿将本灯直接照射眼睛，以免为眼睛造成伤害！

TECHNISCHE DATEN table with columns: ANSIPLATO FL1, TURBO, HELL, MITTEL, DUNKEL, ECO, STROBE, SOS. Rows include Leistungsstufe, Reichweite, Leuchtkraft, and other technical data.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

LIGHTING FOR EXTREMES
FACEBOOK WECHAT
"Follow" us for more information about Fenix.
FENIXLIGHT LIMITED
Tel: +86-755-29631163/83/93 Fax: +86-755-29631181
E-mail: info@fenixlight.com Web: www.fenixlight.com

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

警告
1. 请勿将本灯放置在儿童接触得到的地方，避免儿童使用！
2. 请勿将本灯直接照射眼睛，以免为眼睛造成伤害！

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

警告
1. 请勿将本灯放置在儿童接触得到的地方，避免儿童使用！
2. 请勿将本灯直接照射眼睛，以免为眼睛造成伤害！

技术参数 table with columns: ANSIPLATO FL1, 亮度, 续航时间, 射程, 光强, 防跌落高度, 防护等级. Rows provide technical specifications for the flashlight.

1. 开关状态下，长按顶部功能开关0.5秒以上进入爆闪模式，再次单击顶部功能开关，切换到SOS模式，再次长按0.55返回之前照明方案档位。
2. 开关状态下，长按SET按钮1.25可关闭/打开所有方案下的爆闪模式，而头灯模式则不受影响。

Table with 2 columns: 亮度, 续航时间. Rows show different lighting modes and their corresponding runtime.

警告
1. 请勿将本灯放置在儿童接触得到的地方，避免儿童使用！
2. 请勿将本灯直接照射眼睛，以免为眼睛造成伤害！

TECHNISCHE DATEN table with columns: ANSIPLATO FL1, TURBO, HELL, MITTEL, DUNKEL, ECO, STROBE, SOS. Rows include Leistungsstufe, Reichweite, Leuchtkraft, and other technical data.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

Table with 10 columns: Modus, Eco, Dunkel, Mittel, Hell, Turbo, Strobe, SOS. Rows show different lighting modes and their corresponding settings.

